



- Be sure to **FULLY** attach the reusable adapter to the low side **ONLY**.
- Do not allow time to elapse once the system is running. Quickly, inject the product.
- Recharge the system **AFTER** injecting AC LeakFreeze.
- A caulk gun is helpful when pushing the product in the systems with high pressure on the low side. Insert entire syringe into sleeve of caulk gun and slowly ratchet down on top of the plunger. Always keep your free hand on top of syringe for stability.
- AC LeakFreeze will not cause any damage to gauges.